



**THE DATASHEET OF  
TBPMANN400MGUCV**



## Application Note

### Basic Board Mount Pressure Sensors: TBP Series, Compensated/Unamplified NBP Series, Uncompensated/Unamplified 60 mbar to 10 bar | 6 kPa to 1 Mpa | 1 psi to 150 psi

#### Background

Honeywell's Basic Board Mount Pressure Sensors, TBP Series, Compensated/Unamplified, and NBP Series, Uncompensated/Unamplified, are piezoresistive silicon pressure sensors designed for customers who require a simple, cost-effective, mV output, unamplified, high quality, high resolution solution for medical and industrial applications.

#### Solutions

##### POTENTIAL MEDICAL APPLICATIONS

**Wound Therapy** Wounds may be caused by burns, ulcers, surgery, accidents, or pressure sores (e.g., bedsores). Physicians may use negative-pressure wound therapy (NPWT) to promote healing by creating controlled negative pressure over the wound, helping to promote healing.

*Function in Application:* May be used to monitor the pressure applied to the wound via the suction system.

*Customer Benefits:* Provides maximum therapeutic effect without causing the patient harm.

**Hospital Beds** A hospital bed is designed to be adjustable for patients to ease comfort and to provide patient accessibility by physicians and the nursing staff. The air mattress bed style is generally intended for long-term use by the patient.

*Function in Application:* May be used to monitor the air pressure in the bed so that the desired firmness can be controlled.

*Customer Benefits:* Maintains proper level of pressure so that the firmness can be controlled regardless of the patient's weight. The proper control of the pressure improves patient comfort. Additionally, by helping to facilitate alternating the pressure in the different zones of the mattress, the incidence of bedsores can be reduced. It has been found that by creating different zones in the bed and by alternating the pressure in the various zones, the pressure points experienced by the patient can be varied, which helps prevent bedsores in patients that use the bed for extended use.



Wound therapy - photo used with permission of SunMED Medical Systems



Hospital bed

# Application Note

## Basic Board Mount Pressure Sensors: TBP Series, Compensated/Unamplified NBP Series, Uncompensated/Unamplified 60 mbar to 10 bar | 6 kPa to 1 Mpa | 1 psi to 150 psi

**Oxygen Concentrators** An oxygen concentrator reduces the amount of nitrogen in the air, thereby increasing the oxygen level delivered to the patient. Oxygen concentrators are used with patients, such as those with lung disease, who have difficulty absorbing oxygen into the blood stream.

*Function in Application:* May be used to monitor the pressure internally in the sieve bed so that the sieve bed can generate the required oxygen levels to the patient. Air is comprised mostly of nitrogen (78%) and approximately 21% oxygen. By removing the nitrogen from the air, the concentration of oxygen is significantly increased. There are two sieve beds with zeolite materials that are pressurized with air. By pressurizing the air, the zeolite sieve bed absorbs the nitrogen. The higher the pressure, the more nitrogen is absorbed by the bed, thereby providing a higher concentration of oxygen to the patient. May also be used to detect when the patient begins to inhale so that oxygen can then be delivered efficiently and effectively.

*Customer Benefits:* Controlling the pressure in the sieve bed helps control the concentration of oxygen in the air for the patient. The use of a pressure sensor to monitor when the patient begins to inhale helps to enhance system response time and minimize wasting oxygen when the patient isn't inhaling. This allows the oxygen concentrator to be smaller and to operate more efficiently. Smaller equipment size also means lower power consumption, as well as greater portability.

### POTENTIAL INDUSTRIAL APPLICATIONS

**HVAC Transmitters** Many buildings do not have HVAC system controls in all sections of the building. Instead, transmitters are used in a particular branch of the system so the HVAC master controller can adjust its airflow delivery to those different branches based on information the transmitters send to the HVAC master controller.

*Function in Application:* Can be positioned in outlying areas of the building to provide precise airflow pressure sensing.

*Customer Benefits:* Cost-effective: Reduces system costs by eliminating the need for multiple HVAC system controllers.



Oxygen concentrator



Honeywell transmitter


# Application Note

## Basic Board Mount Pressure Sensors:

TBP Series, Compensated/Unamplified

NBP Series, Uncompensated/Unamplified

60 mbar to 10 bar | 6 kPa to 1 Mpa | 1 psi to 150 psi

Basic Board Mount Pressure Sensors: TBP Series, Compensated/Unamplified NBP Series, Uncompensated/Unamplified	Features and Benefits
	<ul style="list-style-type: none"><li>• <b>Cost-effective sensors with many options:</b> Helps customers to meet their specific application needs</li><li>• <b>Small package size:</b> 7 mm x 7 mm [0.276 in x 0.276 in], which is very small when compared to most board mount pressure sensors, occupying less space on the PCB (printed circuit board) and typically allowing for easy placement on crowded PCBs or in small devices.</li><li>• <b>Wide operating temperature range of -40 °C to 125 °C [-40 °F to 257 °F]:</b> Allows use in many applications.</li><li>• <b>Media compatibility options:</b><ul style="list-style-type: none"><li>- No gel coating: The input port is limited to non-corrosive, non-ionic media such as dry air and gases and should not be exposed to condensation. The gases are limited to media that are compatible with high temperature polyamide, silicone, alumina ceramic, silicon, gold, and glass.</li><li>- Silicone gel coating: Uses the same materials in the wetted media path but is protected from condensation by a silicone-based gel coating; allows use in applications where condensation can occur.</li></ul></li><li>• <b>ROHS AND ISO 9001 compliance</b></li><li>• <b>Many package styles, pressure ranges, silicone gel coating and porting options:</b> Simplifies integration into the device manufacturer's application.</li><li>• <b>Supports lean manufacturing:</b><ul style="list-style-type: none"><li>- J-STD-020-D MSL 1 unlimited shelf life after packaging is opened.</li><li>- System can be calibrated within one hour after reflow solder.</li><li>- Compatible with modern lead-free and no-clean solder processes.</li></ul></li><li>• <b>Manufacturing excellence:</b> Honeywell has more than 100 years of manufacturing and engineering excellence</li><li>• <b>Reliable supply chain:</b> Honeywell's effective inventory management and dependable supply chain are there throughout your product life cycle.</li><li>• <b>Designed to Six Sigma standards:</b> Six Sigma standards provide the highest level of product quality, performance and consistency. Six Sigma provides confidence that the sensor will perform to specification. Many competitive products are produced to lower Sigma tolerances, which may result in some products not performing to the specification to which they were designed.</li><li>• <b>Supporting documentation:</b> Honeywell's Web site provides technical materials to assist you in your application needs.</li></ul>

### Find out more

To learn more about Honeywell's sensing and control products, call **1-800-537-6945**, visit **sensing.honeywell.com**, or e-mail inquiries to **info.sc@honeywell.com**

Sensing and Control

Honeywell

1985 Douglas Drive North

Golden Valley, MN 55422

**honeywell.com**

**Warranty.** Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. **The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.**

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.



008244-3-EN

February 2014

Copyright © 2014 Honeywell International Inc. All rights reserved.

## Looking for pricing, stock, or lifecycle information?

Click below to explore more details on WIN SOURCE:

 [View TBPMANN400MGUCV on WIN SOURCE](#)

 [Honeywell Information](#)

## Optimize Your Supply Chain with WIN SOURCE Solutions

-  Global Sourcing Solution
-  Obsolete Management
-  Cost Control Management
-  Shortage Management
-  Alternative Solution
-  Excess Inventory Management